



Document Camera Cleaning

HoverCam document cameras are precision optical instruments, manufactured using the highest quality materials. They are designed to be used under a wide variety of environments. When cleaning becomes necessary, please use the following guidelines.

1. Disconnect all cables from document camera
2. Lightly moisten a microfiber cloth using the desired hospital grade disinfectant solution. Use care not to soak the microfiber cloth.
3. Use the moistened microfiber cloth to gently wipe the document camera. Be sure to wipe all surfaces. Exercise care when cleaning around the keypad area to ensure no excess cleaning solution finds its way around the function keys.
4. Never spray liquid directly onto the document camera. It could leak into the device and cause damage. Be sure to always apply the cleaning solution directly onto the microfiber cloth and then wipe the camera
5. Use an optical cleaning solution to wipe clean the camera sensor and illumination LED's to ensure optimum image quality.

